




Promjena IP adrese (Vista / Windows 7)


Tring Partner




1. U donjem desnom uglu računara kliknuti desnom tipkom miša na ikonu za mrežne konekcije i odabratи „Open Network and Sharing Center“.




2. Nakon otvaranja prozora, u gornjem lijevom dijelu kliknuti na „Change adapter settings“ (Promijeni postavke adaptera).




3. U novom prozoru, potrebno je desnom tipkom miša kliknuti na ikonu „*Local Area Connection*“, te „*Properties*“ (Svojstva) gdje će se otvoriti novi prozor *Local Area Connection Properties*.




4. Na donjem dijelu prozora kliknuti jednom na „*Internet Protocol Version 4 (TCP/IPv4)*“, te na „*Properties*“ (Svojstva).




5. U novootvorenom prozoru odabratи opciju „*Use the following IP address*“ (Koristi sljedeћe IP adrese). Upisati adresu formata **192.168.10.XX** (Na mjesto XX se upisuje bilo koji broj osim **0, 1, 20 ili 255**), a u polju *Subnet Mask (Maska Podmreže)* broj **255.255.255.0**. Nakon upisa IP adrese, kliknuti na „OK“ (U redu), zatvoriti sve prozore, upaliti Tring Partner i spojiti ga mrežnim kablom sa računarcem.



6. Nakon par sekundi, u donjem desnom uglu monitora ће se pojaviti poruka „*Local Area Connection is now Connected, Speed 10Mbs*“, što znači da smo se uspješno konektovali na Tring PARTNER.
7. Za dodatnu provjeru konekcije sa printerom, koristiti ћemo „ping“ komandu tako što ћemo kliknuti na *START*, i upisati **cmd**.



8. Nakon otvaranja novog prozora, potrebno je upisati slijedeće: **ping 192.168.10.20**, te čemo, ukoliko smo uspješno odradili prethodne korake, dobiti slijedeći rezultat,



The screenshot shows a Microsoft Windows Command Prompt window titled 'C:\WINDOWS\system32\cmd.exe'. The window displays the following text:

```
Microsoft Windows [Version 6.1.7600]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.

C:\Documents and Settings\Korisnik>ping 192.168.10.20
Ping to 192.168.10.20 with 32 bytes of data:
Reply from 192.168.10.20: bytes=32 time=3ms TTL=64
Reply from 192.168.10.20: bytes=32 time=2ms TTL=64
Reply from 192.168.10.20: bytes=32 time=2ms TTL=64
Reply from 192.168.10.20: bytes=32 time=2ms TTL=64

Ping statistics for 192.168.10.20:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 2ms, Maximum = 3ms, Average = 2ms

C:\Documents and Settings\Korisnik>
```

The command 'ping 192.168.10.20' is highlighted with a red oval.


čime računar potvrđuje uspješnu vezu sa printerom.

PROMJENA IP ADRESE NA TRING PARTNERU

Ukoliko je potrebno promijeniti IP adresu na Tring Partneru zbog priključivanja istog na switch ili na router koji imaju drugi opseg IP adresa, potrebno je uraditi slijedeće:

Nakon uspješne promjene adrese na računaru i testiranja komunikacije sa fiskalnim printerom iz prethodnih koraka, u donjem desnom ugлу desktop-a potrebno je kliknuti lijevom tipkom miša na ikonu Tring.Fiscal, čime će se otvoriti prozor servera.

Nakon toga, pritisnuti kombinaciju tipku **CTRL + SHIFT + (slovo) P**, čime će se otvoriti dodatni tab pod nazivom „*Partner*“. U prvoj kartici Partnera, pod nazivom „*Konekcija*“, u polju *IP adresa printer-a*, potrebno je unijeti odgovarajuću adresu iz mreže, te zatim ispod adresu podmreže i gateway-a. Nakon promjene adrese, potvrditi akciju time što se klikne na „*Izmjeni*“. Fiskalni štampač Partner je potrebno ugasiti, isključiti napajanje, sačekati par trenutaka te ga ponovo uključiti.



Nakon što se štampač i računar priključe na switch ili router, potrebno je ponoviti korake 1 do 7, s tim što se u koraku 4 umjesto adrese **192.168.10.XX** na računaru unosi odgovarajuća IP adresa iz postojeće mreže (ili ukoliko je uključen DHCP na routeru, postaviti Automatsko preuzimanje IP adrese), a na komandi „*ping*“ IP adresa štampača koja je prethodno ručno dodijeljena.